


Quick Installation Guide

Wi-Fi 6/6E Router
RX12/TX12/RX12 Pro/TX12 Pro/RX27 Pro/TX27 Pro




Package contents

- Wireless router x 1
- Power adapter x 1
- Ethernet cable x 1
- Quick installation guide


I. Connect the router

1. Power on the router.
2. Connect the WAN port of the router to the LAN port of your modem or the Ethernet jack using an Ethernet cable.
3. Connect your wireless client such as a smartphone to the WiFi network of the router, or use an Ethernet cable to connect the computer to the 1, 2, IPTV/2 or IPTV/3 port of the router. The SSID and password can be found on the bottom label of the device.

3. Set the WiFi name, WiFi password and login password for the router. Click **Next**.



- **Tips**
The WiFi password is used to connect to the WiFi network, while the login password is used to log in to the web UI of the router.



- **Done.**
If the LED indicator of router keeps blinking green slowly for more than 3 minutes, relocate the router and move it closer to the primary node.

- To access the internet with:
 - WiFi-enabled devices: Connect to the WiFi network using the WiFi name and password you set.
 - Wired devices: Connect to a LAN port (1, 2, IPTV/2 or IPTV/3) of the router using an Ethernet cable.

- **Tips**
If you completed the configurations using the **Tenda WiFi App** and want to remotely manage the network, tap on the App home page and use your account to log in.

LED indicator

After the router is powered on for about 40 seconds, the system completes startup. The status of the LED indicator is shown as the following table.

Node Type	LED indicator Status	Description
Primary node	Solid green	The system is starting up, or the router is already connected to the internet.
	Blinking green fast	The router is pending for or performing WPS negotiation or Mesh networking.
	Blinking red slowly	The router failed to connect to the internet.
	Solid green	Networking succeeds. Good connection quality.
Secondary node	Solid orange/yellow	Networking succeeds. Fair connection quality.
	Solid red	Networking succeeds. Poor connection quality.
	Blinking green fast	Networking by the WPS or WPS/MESH button or performing WPS negotiation.
1, 2	Blinking green slowly	Waiting to connect to another node.
	Blinking red slowly	The router failed to connect the internet.

II. Connect the router to the internet

1. Start a browser on the client and enter **tendawifi.com** in the address bar to access the web UI, or run the **Tenda WiFi** app.



2. Perform operations as prompted (computer used as an example).
 - Click **Start Now**.



Jack, ports and buttons

The jacks, ports and buttons may vary with models.

Jack/Port/Button	Description
POWER PWR	Power jack.
RST Reset	Reset button. When the router is working normally, hold the button down using a needle-like item (such as a pin) for about 8 seconds, and then release it when the LED indicator blinks red fast. The router is reset.
WPS WPS/MESH	WPS/Mesh button. <ul style="list-style-type: none"> • WPS: When it is used as a WPS negotiation button, you can connect to the WiFi network of the router without entering the WiFi password. • Method: Press this button for about 1–3 seconds. The LED indicator blinks fast. Within 2 minutes, enable the WPS function of the other WPS-supported device to establish a WPS connection. • Mesh: When it is used as a Mesh networking button, you can extend your network with another device that supports the Mesh function. • Method: Press this button for about 1–3 seconds. The LED indicator blinks green fast, which indicates the device is searching for another device to form a network. Within 2 minutes, press the MESH/WPS button of another device for 1 to 3 seconds to negotiate with this device.
WAN	10/100/1000 Mbps auto-negotiation WAN port. Used to connect to a modem or the Ethernet jack using an Ethernet cable for internet access. <ul style="list-style-type: none"> • Tips After the router is connected to an existing network as a secondary node, this WAN port is used as a LAN port.
1, 2	10/100/1000 Mbps auto-negotiation LAN port. Used to connect to computers, switches or game machines, etc.
IPTV/3 IPTV/2	10/100/1000 Mbps auto-negotiation LAN/IPTV port. It is a LAN port by default. When the IPTV function is enabled, it can only serve as an IPTV port to connect to a set-top box.


Scenario 2: Set up as an add-on node

I. Add the router to an existing network

- **Tips**
Please ensure that the router has never been used. If not, reset it first. Currently, RX12, TX12, RX12 Pro, TX12 Pro, RX27 Pro, TX27 Pro, Mesh6X, Mesh12X, Mesh 15XP and Mesh21XEP can be networked with each other.

1. Place the router in an elevated and open position within 3 meters from your existing node.
2. Use the power adapter to connect the router to a power source, and wait until its LED indicator blinks green slowly.
3. Press the **WPS/MESH** button of the router for about 3 seconds. The LED indicator blinks green fast. Within 2 minutes, press the **MESH/WPS** button of the node of the existing network for 3 seconds to negotiate with this router.

When the LED indicator of the router lights solid green, the networking is successful and the router becomes a secondary node in the network.



- **Tips**
The product appearance may vary with models. Please refer to the product you purchased.

Solid green	Networking succeeds. Excellent connection quality.
Solid orange/yellow	Networking succeeds. Fair connection quality.
Solid red	Networking succeeds. Poor connection quality.

4. If the router's LED indicator blinks red slowly, relocate it by repeating the preceding steps to get an optimal connection quality.

- **Done.**
To access the internet with:
 - Wired devices: Connect to the LAN ports of your nodes.
 - Wireless devices: Connect to your WiFi network using the WiFi name and password of your existing WiFi network.

FAQ

- Q1: I cannot log in to the web UI of the router by visiting **tendawifi.com**. What should I do?

- A1: Try the following solutions:
 - If you are using a WiFi-enabled device, such as a smartphone:
 - Ensure that it connects to the WiFi network of the router.
 - Ensure that the cellular network (mobile data) of the device is disabled.
 - If you are using a wired device, such as a computer:
 - Ensure that **tendawifi.com** is entered correctly in the address bar, rather than the search bar of the web browser.
 - Ensure that the computer is connected to the LAN port of the router properly using an Ethernet cable.
 - Ensure that the computer is set to **Obtain an IP address automatically** and **Obtain DNS server address automatically**.

- Q2: How to restore my device to factory settings?
- A2: When your device is working properly, hold down the **RST** or **Reset** button of your device using a needle-like item (such as a pin) for about 8 seconds, and release it when the LED indicator blinks red fast. When the LED indicator lights solid green, your device is reset successfully.

- Q3: The device failed to be detected by the Tenda WiFi app upon my first time using the device. What should I do?

- A3: Try the following solutions:
 1. Ensure that your smartphone is connected to the default WiFi network of the device.
 2. Ensure that the network permission of **Tenda WiFi** app is enabled, you can tap **Settings** > **Tenda WiFi** to enable it.

If the problem persists, please reset the router and try again.

- Q4: I cannot find the 5 GHz/6 GHz WiFi network of the router on my WiFi-enabled device. What should I do?

- A4: Try the following solutions:
 - Check whether your WiFi-enabled device supports 5 GHz or 6 GHz WiFi network. Only devices supporting 5 GHz/6 GHz network can find and connect to the 5 GHz/6 GHz WiFi network.
 - Check whether you have enabled **Unify 2.4 GHz & 5 GHz** or **Unify 2.4 GHz & 5 GHz & 6 GHz** on the WiFi Settings page. If it is enabled, disable it and try again.

- Q5: When I use the product as a router, I cannot access the internet after the configuration. What should I do?

- A5: Try the following solutions:
 - Check whether the WAN port of the router is connected to a modem or Ethernet jack properly.
 - Log in to the web UI of the router and navigate to the **Internet Settings** page. Follow the instructions on the page to solve the problem.

- If the problem persists, try the following solutions:
 - For WiFi-enabled devices:
 - Check whether your WiFi-enabled devices are connected to the WiFi network of the router.
 - Visit **tendawifi.com** to log in to the web UI and change your WiFi name and WiFi password on the **WiFi Settings** page. Then try again.
 - For wired devices:
 - Check whether your wired devices are connected to a LAN port properly.
 - Check whether wired devices are set to **Obtain an IP address automatically** and **Obtain DNS server address automatically**.

Wall Mounting
This router can be installed on the wall with two screws. The recommended wall mounting tools are as follows:
[Expansion bolt] Outer diameter: 6.0 mm; Length: 26.4 mm
[Screws] Thread diameter: 3 mm; Length: 14 mm; Head diameter: 5.2 mm

Get support and services

For technical specifications, user guides and more information, please visit the product page or service page on **www.tenda.com**. Multiple languages are available. You can see the product name and model on the product label.



<https://www.tenda.com/service/default.html>

Safety Precautions

- Before performing an operation, read the operation instructions and precautions to be taken, and follow them to prevent accidents. The warning and danger items in other documents do not cover all the safety precautions that must be followed. They are only supplementary information, and the installation and maintenance personnel need to understand the basic safety precautions to be taken.
- The device is for indoor usage only.
- For desktop mounting, the device must be horizontally mounted for safe use.
- If the device supports wall mounting, the device is only suitable for mounting at heights ≥ 2 m.
- Do not use the device in a place where wireless devices are not allowed.
- Please use the included power adapter.
- Mains plug is used as the disconnect device, and shall remain readily operable.
- The power socket shall be installed near the device and easily accessible.
- Operating environment: Temperature: 0°C – 40°C; Humidity: (10% – 90%) RH, non-condensing. Storage environment: Temperature: –40°C to +70°C; Humidity: (5% – 90%) RH, non-condensing.
- Keep the device away from water, fire, high electric field, high magnetic field, and inflammable and explosive items.
- Unplug this device and disconnect all cables during lightning storms or when the device is unused for long periods.
- Do not use the power adapter if its plug or cord is damaged.
- If such phenomena as smoke, abnormal sound or smell appear when you use the device, immediately stop using it and disconnect its power supply, unplug all connected cables, and contact the after-sales service personnel.
- Disassembling or modifying the device or its accessories without authorization voids the warranty, and might cause safety hazards.
- For latest safety precautions, see **Safety and Regulatory Information** on **www.tenda.com.cn**.



Technical Support
Shenzhen Tenda Technology Co., Ltd.
Floor 6–8, Tower E3, No.1001, Zhongshanyuan Road, Nanshan District, Shenzhen, China, 518052.
Website: www.tenda.com
E-mail: support@tenda.com
support.uk@tenda.com (United Kingdom)
support.us@tenda.com (North America)

Copyright
©2023 Shenzhen Tenda Technology Co., Ltd. All rights reserved.
Tenda is a registered trademark legally held by Shenzhen Tenda Technology Co., Ltd. Other brand and product names mentioned herein are trademarks or registered trademarks of their respective holders. Specifications are subject to change without notice.

CE Mark Warning
This is a Class B product. In a domestic environment, this product may cause radio interference, in which case the user may be required to take adequate measures.

This equipment should be installed and operated with a minimum distance 20cm between the device and your body.

NOTE: (1) The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications to this equipment. (2) To avoid unnecessary radiation interference, it is recommended to use a shielded RJ45 cable.

Declaration of Conformity
Hereby, SHENZHEN TENDA TECHNOLOGY CO., LTD. declares that the device is in compliance with Directive 2014/53/EU.

The full text of the EU declaration of conformity is available at the following internet address:
<https://www.tenda.com/download/8st-9.html>

English: Operating Frequency/Max Output Power	
Polish: Częstotliwość pracy / Maksymalna moc wyjściowa	
Deutsch: Betriebsfrequenz/Max. Ausgangsleistung	
Русский: Рабочая частота/Макс. выходная мощность	
Franciais: Fréquence de fonctionnement/Puissance de sortie maximale	
Nederlands: Bestrijfrequentie/Maximale uitgangsvermogen	
Čeština: Provozní frekvence/Maximální výstupní výkon	
Română: Frecvența de funcționare/Putea maximă de ieșire	
Portuguese: Frequência de Funcionamento/Potência Máxima de Saída	
Svenska: Driftfrekvens / Max Utteffekt	
Slovensky: Prevádzková frekvencia/Maximálny výstupný výkon	
Ελληνικά: Συχνότητα Λειτουργίας/Μέγιστη Ισχύς Εξόδου	
Magyar: Működési frekvencia/Maximális kimeneti teljesítmény	
Italiano: Frequenza operativa/Potenza di uscita massima	
Български: Работна честота/Максимална изходна мощност	
Español: Frecuencia operativa/Potencia de salida máxima	
Català: Totaopducció de treball/ Potència màxima de sortida	
Dansk: Driftsfrekvens/Maks. Udgangseffekt	
Finnish: Toimintaajatus/Maksimilähtöteho	
Hrvatski: Radna frekvencija/Maksimalna izlazna snaga	
Latvieski: Radna frekvencija/Maksimālā jauda	
Lietuvai: Darbinis dažnis /maksimali išėjimo galia	
Slovenščina: Delovna frekvenca/Največja izhodna moč	
Türkçe: Çalışma Frekansı/Maks. Çıkış Gücü	
عربی: تردد التشغيل / الحد الأقصى للإخراج	



RECYCLING
This product bears the selective sorting symbol for Waste electrical and electronic equipment (WEEE). This means that this product must be handed pursuant to European directive 2012/19/EU in order to be recycled or dismantled/ to minimize its impact on the environment.
User has the choice to give his product to a competent recycling organization or to the retailer when he buys a new electrical or electronic equipment.

