

Tenda

Web User Guide (for Mobile)

Dual Band Wi-Fi 7 Router



Copyright statement

© 2024 Shenzhen Tenda Technology Co., Ltd. All rights reserved.

Tenda is a registered trademark legally held by Shenzhen Tenda Technology Co., Ltd. Other brand and product names mentioned herein are trademarks or registered trademarks of their respective holders. Copyright of the whole product as integration, including its accessories and software, belongs to Shenzhen Tenda Technology Co., Ltd. No part of this publication can be reproduced, transmitted, transcribed, stored in a retrieval system, or translated into any language in any form or by any means without the prior written permission of Shenzhen Tenda Technology Co., Ltd.

Disclaimer

Pictures, images and product specifications herein are for references only. To improve internal design, operational function, and/or reliability, Tenda reserves the right to make changes to the products without obligation to notify any person or organization of such revisions or changes. Tenda does not assume any liability that may occur due to the use or application of the product described herein. Every effort has been made in the preparation of this document to ensure accuracy of the contents, but all statements, information and recommendations in this document do not constitute a warranty of any kind, express or implied.

Preface

Thank you for choosing Tenda! This guide is a complement to Quick Installation Guide. The Quick Installation Guide provides instructions for quick internet setup, and this guide demonstrates how to configure functions by logging in to the device's web UI with the mobile clients.

Applicable model

This user guide walks you through all functions on the Tenda Wi-Fi 7 Routers. All the screenshots and product figures herein, unless otherwise specified, are taken from RE6L Pro.

Conventions

This guide is for reference only and does not imply that the product supports all functions in the guide. The functions supported by different models or different versions of the same model may differ. The actual product prevails.

The product figures and screenshots in this guide are for examples only. They may be different from the actual products you purchased, but do not affect the normal use.

If the function or parameter is displayed in gray on the product UI interface, the product model is not supported or cannot be modified.



In this guide, unless otherwise specified:

- The firmware version uses V16.03.53.04 of RE6L Pro as an example.
- The iOS system is used for illustration here.

The typographical elements that may be found in this document are defined as follows.

Item	Presentation	Example
Cascading menus	>	System > Live Users
Parameter and value	Bold	Set User Name to Tom .
Variable	Italic	Format: <i>XX:XX:XX:XX:XX:XX</i>
UI control	Bold	On the Policy page, tap the OK button.
Message	“ ”	The “Success” message appears.

The symbols that may be found in this document are defined as follows.

Symbol	Meaning
 NOTE	This format is used to highlight information of importance or special interest. Ignoring this type of note may result in ineffective configuration, loss of data or damage to device.
 TIP	This format is used to highlight a procedure that will save time or resources.

For more documents

If you want to get more documents of the device, visit www.tendacn.com and search for the corresponding product model.

Technical support

Contact us if you need more help. We will be glad to assist you as soon as possible.

Email address: support@tenda.cn

Website: www.tendacn.com

Revision history

Tenda is constantly searching for ways to improve its products and documentation. The following table indicates any changes that might have been made since the router was introduced.

Version	Date	Description
V1.0	2024-10-12	Original publication.

Contents

MESH networking	1
1.1 Overview	1
1.2 Set up as an add-on node	1
1.3 Remove the secondary node from the network	5
Connect the client to the router's network	7
2.1 Wireless network connection	8
2.2 WPS connection	9
Log in to the web UI of the router	12
Internet settings	15
4.1 Modify IPv4 internet settings	16
4.2 IPv6 settings	26
4.3 Modify MTU	38
4.4 Clone MAC address	40
4.5 Change the device's working mode	42
Wi-Fi settings	57
5.1 Change Wi-Fi name and Wi-Fi password	58
5.2 Guest Wi-Fi settings	59
5.3 Change the Wi-Fi signal strength	62
Network status	64
6.1 View network status	65
6.2 View Wi-Fi name	70
6.3 View the networking information	71
6.4 View the number of the clients	74
6.5 View client details	75
6.6 View router information	79
Client management	80
7.1 Add a client to the blacklist	81
7.2 Remove a client from the blacklist	83
7.3 Internet access speed control	85
7.4 Internet access rule control	87
Optimize network performance	93
Turn on or turn off the indicator of router	95
9.1 Turn on or turn off the indicators of all nodes	96
9.2 Schedule turn off the indicators of all nodes	99
9.3 Turn on or turn off the indicators of single node	101
Change the router's login password	103
System maintenance	105

11.1 Reboot device	106
11.2 Firmware upgrade	114
11.3 Reset	115
More functions	119
Appendixes	120
A.1 FAQ	120
A.2 Acronyms and Abbreviations	124

1 MESH networking

This guide is for reference only and does not imply that the product supports all functions in the guide. The functions may differ with product models. The actual product prevails.

This chapter introduces Mesh networking methods in the following sections:

[Overview](#)

[Set up as an add-on node](#)

[Remove the secondary node from the network](#)

1.1 Overview

Tenda WiFi+ routers support Mesh networking. Mesh networking has such advantages as automatic networking, self-repair, multi-skip cascade, unified management network, and node self-management, which can greatly reduce the cost and complexity of network deployment.

1.2 Set up as an add-on node

This section describes how to add a new router to extend the wireless network coverage when a router is connected to the internet.

If you are using the router for the first time or have restored the router to factory settings, follow the quick installation guide of the corresponding router model to configure the router to the internet.




TIP

- If there are more than two secondary nodes, place the primary node in the key area and ensure that no more than one node is between the primary node and the secondary node.
- Before using a new router to extend the network, ensure that the existing router (primary node) has been connected to the internet and the new router (secondary node) is restored to the factory settings.
- The router can be networked with **Tenda WiFi+** routers. If the router fails to be added to an existing network, contact Tenda customer service for help. The following uses two RE6L Pro routers as an example.

Step 1 [Log in to the web UI of the router](#), and tap **Network Topology**.

Step 2 Tap  (**Add Node**).





Step 3 The system discovers new nodes, select the new router based on the MAC address or Serial Number (SN) of the device, and tap **Start**. The following figure is for reference only.



TIP


- The MAC address and SN of the device can be found on the label of the device body.
- You can add only one node at a time by scanning.

Step 4 Wait for a moment, the node is added successfully, and tap **OK**.



---End

On the **Network Topology** page, you can see that the new RE6L Pro has been successfully added to the network as a secondary node.



To access the internet with:

- **Wired devices:** Connect to any Ethernet port of the node using an Ethernet cable.
- **Wi-Fi-enabled devices:** Connect to the Wi-Fi network of the node. (The Wi-Fi name and Wi-Fi password of all nodes are the same.)

1.3 Remove the secondary node from the network


Removing the secondary node will reduce the network coverage and the node will be restored to factory settings.

Use this function as required. For example, if you use two routers to network, one can cover the whole house after actual installation. You can remove the other one from the network and then give your friend.



Configuration procedure:

Step 1 [Log in to the web UI of the router.](#)

Step 2 Tap **Network Topology**, locate and tap the secondary node you want to remove. The following figure is for reference only.



Step 3 Tap  (**Delete Node**). Confirm the prompt message, and tap **OK**.



---End

2 Connect the client to the router's network

This guide is for reference only and does not imply that the product supports all functions in the guide. The functions may differ with product models. The actual product prevails.

This chapter introduces how to connect the client to the router's network in the following sections:


[Wireless network connection](#)

[WPS connection](#)

2.1 Wireless network connection

The smartphone is taken as an example.

Connect the smartphone to the router's wireless network. The **@Tenda_A4F170** is taken as an example here.



- At the first login, connect the SSID (Wi-Fi name) on the label of the device.
 - When you log in to the router again, use the new Wi-Fi name and Wi-Fi password to connect to the wireless network.
-

2.2 WPS connection

The WPS function enables Wi-Fi-enabled devices, such as smartphones, to connect to Wi-Fi networks of the router without entering the password.


NOTE

The wireless network whose encryption mode is WPA3 does not support WPS connection. To use the WPS function of the router, you are recommended to set the encryption mode of the router's wireless network to **WPA2-PSK**.


Method 1: Connect to the router's Wi-Fi through PBC


Step 1 Enable the WPS-PBC function on the router.

Press the MESH button on the router body. The router's indicator blinks fast.




Step 2 Configure the WPS function on your Wi-Fi-enabled devices **within 2 minutes**. Configuration on various devices may differ (Example: HUAWEI P10).


1. Find WLAN settings on your phone.
2. Tap , and choose **WLAN settings**.



3. Choose **WPS** connection.



Wait until the WPS negotiation completes. Now the phone is connected to the Wi-Fi network.



---End

Method 2: Connect to the router's Wi-Fi through PIN code



This method only supports entering the WPS PIN code of the router on the wireless clients to connect to the router's Wi-Fi. It is usually used for wireless network adapter to connect to the router's Wi-Fi. For details, see the user guide of the corresponding wireless network adapter.

- Step 1** Check and record the WPS PIN code (Pin No) on the label of the router.
- Step 2** Enter the WPS PIN code of the router on the wireless clients for connection. The connection is successful within 2 minutes.

---End


3 Log in to the web UI of the router

This guide is for reference only and does not imply that the product supports all functions in the guide. The functions may differ with product models. The actual product prevails.


The smartphone is taken as an example.

Configuration procedure:

Step 1 [On the smartphone connected to the router](#), start a browser and enter **tendawifi.com** in the address bar to log in to the web UI.



Step 2 Enter the login password, and tap **Login**.



---End

After logging in to the router's web UI, you can configure the router as required.




If the login page does not appear, try the following solutions.

- Ensure that the router is powered properly, and the smartphone is connected to the router's Wi-Fi.
- Ensure that the mobile data traffic is disabled.
- Use the router's default IP address (<http://tendawifi.com> or <http://192.168.0.1>) to log in to the web UI.
- [Restore the router to factory settings](#) and try again.

If you forgot the login password, try the following solutions.

- Try to use the Wi-Fi password to log in to the router.
- If the problem persists, [restore the router to factory settings](#) and try again.



4 Internet settings

This guide is for reference only and does not imply that the product supports all functions in the guide. The functions may differ with product models. The actual product prevails.

This chapter includes the following parts:

[Modify IPv4 internet settings](#)

[IPv6 settings](#)

[Modify MTU](#)

[Clone MAC address](#)

[Change the device's working mode](#)

4.1 Modify IPv4 internet settings

By configuring the internet settings, you can achieve shared internet access (IPv4) for multiple users within the LAN.


If you are configuring the router for the first time or after restoring it to factory settings, refer to the quick installation guide of the corresponding router to configure the internet access. After that, you can change the internet settings by following the instructions in this chapter.



Parameters for internet access are provided by your ISP. Contact your ISP for any doubt.

4.1.1 Access the internet with a PPPoE account

If the ISP provides you with the PPPoE user name and password, you can choose this connection type to access the internet. The application scenario is shown below.



By default, the WAN/LAN auto-negotiation function of the router is enabled, and the Ethernet cable connected to the internet can be connected to any Ethernet port. If the WAN/LAN auto-negotiation function is disabled, connect the Ethernet cable connected to the internet to Ethernet port 1 (WAN port).

To access the internet with a PPPoE account:

Step 1 [Log in to the web UI of the router](#), and navigate to **Internet Settings**.

Step 2 Set **ISP Type** to **Normal**.


Step 3 Set **Internet Connection Type** to **PPPoE**.

Step 4 Enter the **PPPoE Username** and **PPPoE Password** provided by your ISP.

Step 5 Perform advanced settings as required.


- If the ISP provides **Server Name** and **Service Name**, enter the corresponding parameters in the corresponding box. If not, keep it as default.
- In general, DNS settings can be kept as default. If your ISP provides a DNS address, change the DNS settings to **Manual** and fill in the correct DNS address. If there is only one DNS address, please fill in the **Primary DNS**.

Step 6 Tap **Connect**.



---End

Wait until the network status changes to **Connected**, then you can access the internet.




If you cannot access the internet, refer to [Router disconnected from the internet](#) to resolve the problem.

4.1.2 Access the internet through a dynamic IP address

Generally, accessing the internet through a dynamic IP address is applicable in the following situations:

- Your ISP does not provide the PPPoE user name and password, or any other information including IP address, subnet mask, default gateway and DNS server.
- You already have a router with internet access and want to add another router.

The application scenario is shown below.




By default, the WAN/LAN auto-negotiation function of the router is enabled, and the Ethernet cable connected to the internet can be connected to any Ethernet port. If the WAN/LAN auto-negotiation function is disabled, connect the Ethernet cable connected to the internet to Ethernet port 1 (WAN port).

To access the internet through dynamic IP address:

- Step 1** [Log in to the web UI of the router](#), and navigate to **Internet Settings**.
- Step 2** Set **ISP Type** to **Normal**.
- Step 3** Set **Internet Connection Type** to **Dynamic IP**.
- Step 4** Perform advanced settings as required.


In general, DNS settings can be kept as default. If your ISP provides a DNS address, change the DNS settings to **Manual** and fill in the correct DNS address. If there is only one DNS address, please fill in the **Primary DNS**.

- Step 5** Tap **Connect**.



---End

Wait until the network status changes to **Connected**, then you can access the internet.



If you cannot access the internet, refer to [Router disconnected from the internet](#) to resolve the problem.

4.1.3 Access the internet with a set of static IP address information

When your ISP provides you with information including IP address, subnet mask, default gateway and DNS server, you can choose this connection type to access the internet.

Configuration procedure:

Step 1 [Log in to the web UI of the router](#), and navigate to **Internet Settings**.


Step 2 Set **ISP Type** to **Normal**.

Step 3 Set **Internet Connection Type** to **Static IP**.

Step 4 Set **IP Address**, **Subnet Mask**, **Default gateway** and **Primary DNS**, and **Secondary DNS** with the information provided by your ISP.

If there is only one DNS address, please fill in the **Primary DNS**.

Step 5 Tap **Connect**.



---End

Wait until the network status changes to **Connected**, then you can access the internet.



If you cannot access the internet, refer to [Router disconnected from the internet](#) to resolve the problem.

4.1.4 Set up dual access connection

In countries like Russia, the ISP may require you to set up dual access. One is for access to the internet through PPPoE, PPTP or L2TP, and the other is for access to the “local” resources where the ISP is located through DHCP or static IP address. If your ISP provides such connection information, you can set up dual access to access the internet.

Configuration procedure:


Step 1 [Log in to the web UI](#), and navigate to **Internet Settings**.

Step 2 Set **ISP Type** to **Russia**.

Step 3 Set **Internet Connection Type**, which is **Russia PPTP** in this example, and fill in required parameters.


If there is only one DNS address, please fill in the **Primary DNS**.

Step 4 Tap **Connect**.



---End

Wait until the network status changes to **Connected**, then you can access the internet.



4.2 IPv6 settings

4.2.1 Overview

IPv6, abbreviated for Internet Protocol Version 6, is the second-generation network layer protocol. IPv6 is an upgraded version of Internet Protocol version 4 (IPv4), which is the solution that addresses the relatively limited number of IP addresses possible under IPv4.

An IPv6 address is 128 bits long and is arranged in eight groups, each of which is 16 bits. Each group is expressed as four hexadecimal digits and the groups are separated by colons. An IPv6 address is split into two parts:

- Network Prefix: n bits, equivalent to the network ID in the IPv4 address.
- Interface Identifier: 128-n bits, equivalent to the host ID in the IPv4 address.

This router supports IPv4 and IPv6. You can connect to the IPv6 network of ISPs through IPv6 WAN settings.

The router can access the IPv6 network of ISPs through three connection types. Choose the connection type by referring to the following chart.

Scenario	Connection Type
<ul style="list-style-type: none"> • The ISP does not provide any PPPoEv6 user name and password and information about the IPv6 address. • You have a router that can access the IPv6 network. 	DHCPv6
IPv6 service is included in the PPPoE user name and password.	PPPoEv6
The ISP provides you with a set of information including IPv6 address, subnet mask, default gateway and DNS server.	Static IPv6 address



TIP

- Before configuring the IPv6 function, ensure that you are within the coverage of the IPv6 network and already subscribe to the IPv6 internet service. Contact your ISP for any doubt about it.
- The router supports automatic NAT66. If the LAN port cannot obtain a prefix after IPv6 is configured, the upstream device may not support PD prefix delivery. In this case, the router automatically enables the NAT66 function.


4.2.2 IPv6 WAN settings

DHCPv6

DHCPv6 enables the router to obtain an IPv6 address from the DHCPv6 server to access the internet. It is applicable in the following scenarios:

- The ISP does not provide any PPPoEv6 user name and password and information about the IPv6 address.
- You have a router that can access the IPv6 network.

The application scenario is shown below.





TIP

By default, the WAN/LAN auto-negotiation function of the router is enabled, and the Ethernet cable connected to the internet can be connected to any Ethernet port. If the WAN/LAN auto-negotiation function is disabled, connect the Ethernet cable connected to the internet to Ethernet port 1 (WAN port).

Configuration procedure:


Step 1 [Log in to the web UI of the router.](#)

Step 2 Navigate to **More > IPv6**.



Step 3 Set **Internet Connection Type** to **DHCPv6**.

Step 4 Tap **Save** in the upper-right corner.




---End

After the settings are completed, you can perform [IPv6 network test](#) to check whether IPv6 network settings are successful.



PPPoEv6

If your ISP provides you with the PPPoE user name and password with IPv6 service, you can choose PPPoEv6 to access the internet.




TIP

By default, the WAN/LAN auto-negotiation function of the router is enabled, and the Ethernet cable connected to the internet can be connected to any Ethernet port. If the WAN/LAN auto-negotiation function is disabled, connect the Ethernet cable connected to the internet to Ethernet port 1 (WAN port).

Configuration procedure:**Step 1** [Log in to the web UI of the router.](#)**Step 2** Navigate to **More > IPv6**.**Step 3** Set **Internet Connection Type** to **PPPoEv6**.**Step 4** Set **PPPoE Username** and **PPPoE Password**.

Generally, IPv4 and IPv6 services share single PPPoE user name and password.

Step 5 Tap **Save** in the upper-right corner.



---End

After the settings are completed, you can perform [IPv6 network test](#) to check whether IPv6 network settings are successful.


Static IPv6 address

When your ISP provides you with information including IPv6 address, subnet mask, default gateway and DNS server, you can choose this connection type to access the internet with IPv6.

Configuration procedure:

Step 1 [Log in to the web UI.](#)

Step 2 Navigate to **More > IPv6**.




Step 3 Set the **Internet Connection Type** to **Static IPv6 Address**.

Step 4 Enter the **IPv6 Address**, **Default IPv6 Gateway** and **Primary/Secondary IPv6 DNS** provided by the ISP.

If the ISP only provides a single DNS address, **Secondary IPv6 DNS** can be left blank.

Step 5 Tap **Save** in the upper-right corner.



The network prefix of the LAN IPv6 address.


---End

After the settings are completed, you can perform [IPv6 network test](#) to check whether IPv6 network settings are successful.

IPv6 network test

On a Wi-Fi-enabled device, such as a smartphone, that is connected to the router, launch a browser and visit **test-ipv6.com** to the test page, which will give you feedback on your network status.

As shown in the following figure, when the page shows your IPv6 address and clearly states "Since you have IPv6", IPv6 setup is successful and you can access IPv6 services.




If the IPv6 network test fails, try the following solutions:

- Ensure that the IPv6 address obtaining type of Wi-Fi-enabled devices such as a laptop or computer is set to **Obtain an IPv6 address automatically** and **Obtain DNS server address automatically**.
- If the internet connection type is static IPv6 address, ensure that the IPv6 address of the WAN port, subnet prefix length, default gateway, and DNS are correct.
- Consult your ISP for help.

4.2.3 IPv6 LAN settings

To access the configuration page, [log in to the web UI of the router](#), and navigate to **More > IPv6**.

Locate the **Assignment Method** module, you can configure the method for LAN IPv6 clients to obtain IPv6 addresses, and LAN port prefix addresses, to achieve multiple clients in the LAN to share your broadband service to access the internet.



Parameter description

Parameter	Description	
Assignment Method	Auto	Specifies the stateful configuration and stateless configuration. The IPv6 prefix address, and DNS server address of the client can be obtained from the DHCPv6 server or through Route Advertisement (RA). The gateway address can be obtained from RA.
	SLAAC	Specifies the DHCPv6 stateless configuration. The IPv6 prefix address and gateway address of the client are obtained through RA, the interface address is generated based on the standard, and the DNS server address is obtained from the DHCPv6 server.

Parameter	Description
SLAAC+RDNSS	Specifies the stateless address automatic configuration. The IPv6 prefix address and gateway address of the client are obtained through RA, the interface address is generated based on the standard, and the DNS server address is obtained from the RDNSS option in the RA packet.
DHCPv6	Specifies the stateful configuration of Dynamic Host Configuration Protocol for IPv6 (DHCPv6). The client obtains the complete IPv6 address information, including the DNS server address, from the DHCPv6 server. The gateway address is obtained through RA.

4.3 Modify MTU

Maximum Transmission Unit (MTU) is the largest data packet that a network device transmits.

Generally, keep the default MTU value. Try to change the MTU value when:

- You cannot access some specific websites or encrypted websites (such as E-banking or PayPal websites).
- You cannot receive and send Emails or access an FTP or POP server.



You can try reducing the value of MTU gradually from 1500 until the problem is resolved (The recommended range is 1400 to 1500).

MTU application description

MTU	Application
1500	Used for the most common settings in non-PPPoE connections and non-VPN connections.
1492, 1480	Used for PPPoE connections.
1472	It is the maximum value for the ping command. A packet with a larger size is fragmented.
1468	Used for DHCP connections.
1436	Used for VPN connections.

To access the configuration page, [log in to the web UI of the router](#), and navigate to **Internet Settings**, and tap **Advanced**.

When the internet connection type is **PPPoE**, the default MTU value is **1480**. If the internet connection type is set to **Dynamic IP** or **Static IP**, the default MTU value is **1500**.



4.4 Clone MAC address

When the internet settings are completed, if the router still cannot be connected to the internet, the ISP may be bound to a certain MAC address (physical address). You can try to solve the problem through MAC address cloning.

Clone WAN MAC address



Use the correct MAC address to clone. The correct MAC address is the MAC address of the computer that can access the internet when the router is not in use, or the MAC address of the router's WAN port that can access the internet before.

Configuration procedure:

Step 1 [Log in to the web UI of the router.](#)

Step 2 Navigate to **Internet Settings**, and tap **Advanced**.


Step 3 Tap the drop-down menu of **MAC Address Clone** to change the MAC address.

- If you are using "a computer that can access the internet when the router is not in use to configure the router", select **Clone Local Host MAC**.
- If you are using another computer to configure the router, select **Custom** and fill in the correct MAC address (this could be "MAC address of the computer that successfully connected to the internet when connected directly to the Ethernet cable" or "MAC address of the router's WAN port that was previously connected to the internet").



To restore the MAC address of the WAN port to the factory MAC address, set **MAC Address Clone** to **Default MAC**.

Step 4 Tap **Connect**.



---End

4.5 Change the device's working mode

By default, the device works in router mode. You can select a working mode based on the following scenarios:

- **Router mode:** The wired network provided by the ISP is converted into Wi-Fi signal, and the LAN users can share the internet.
- **AP mode:** Used as an AP to extend the network coverage by connecting the upstream devices through Ethernet cables.
- **WISP mode:** To bridge the hotspot of ISPs.
- **Client+AP mode:** To bridge all kinds of Wi-Fi networks.

4.5.1 AP mode

When you have a smart home gateway that only provides wired internet access, you can set the router to work in AP mode to provide wireless coverage.



TIP

When the router is set to AP mode:


- Every physical port can be used as a LAN port.
 - The router's LAN IP address will change. If you want to log in to the web UI of the router, use the **tendawifi.com** to log in.
 - Functions, such as bandwidth control and port mapping will be unavailable. Refer to the web UI for available functions.
-

To switch the working mode to AP mode:


Step 1 Connect your Wi-Fi-enabled device such as a smartphone to the router's Wi-Fi.

Step 2 Set the router to **AP Mode**.


1. [Log in to the web UI of the router](#). Navigate to **More > Working Mode**.



2. Tap **Switch Mode** after **AP Mode**. Confirm the prompt message, and tap **OK**. The page will be prompted to reboot. Please wait with patient.




3. Connect the upstream device, such as a gateway, to any port of the router.



[Log in to the web UI of the router](#) again, and check whether the AP mode is configured successfully as shown below.

You can access the internet by connecting the computers to any Ethernet port of the router, or connecting the Wi-Fi-enabled devices such as smartphones to the router's Wi-Fi.



TIP

If you cannot access the internet, try the following solutions:

- Ensure that the existing router is connected to the internet successfully.
- Ensure that your Wi-Fi-enabled devices are connected to the correct Wi-Fi network of the router.
- If the computer connected to the router cannot access the internet, ensure that the computer is set to **Obtain an IP address automatically** and **Obtain DNS server address automatically**.

4.5.2 Router mode


Scenario: The router is working in AP mode.

Goal: Now you have moved to a new home, the ISP provides a PPPoE username and password for internet access, or provides internet access information such as an IP address, subnet mask, default gateway, and DNS server.


Solution: Reconfigure the router and set its working mode to **Router Mode**.

To switch the working mode from the other modes to router mode:


Step 1 [Log in to the web UI of the router.](#) Navigate to **More > Working Mode**.



Step 2 Tap **Switch Mode** after **Router Mode**. Confirm the prompt message, and tap **OK**. The page will be prompted to reboot. Please wait with patient.



Step 3 Connect the WAN port of the router to the Ethernet jack or the LAN port of the Modem using an Ethernet cable.






By default, the WAN/LAN auto-negotiation function of the router is enabled, and the Ethernet cable connected to the internet can be connected to any Ethernet port. If the WAN/LAN auto-negotiation function is disabled, connect the Ethernet cable connected to the internet to Ethernet port 1 (WAN port).

Step 4 Configure the router to the internet. For details, see [Internet settings](#).

--End

[Log in to the web UI of the router](#) again, and check whether the router mode is configured successfully as shown below.

You can access the internet by connecting the computers to the router's Ethernet port (If the WAN/LAN auto-negotiation function is disabled, connect the computer to any Ethernet port 2/3/4 of the router.), or connecting the Wi-Fi-enabled devices such as smartphones to the router's Wi-Fi.



If you cannot access the internet, try the following solutions:

- Ensure that your Wi-Fi-enabled devices are connected to the correct Wi-Fi network of the router.
- If the computer connected to the Ethernet port of the router (If the WAN/LAN auto-negotiation function is disabled, connect the computer to any Ethernet port 2/3/4 of the router.) cannot access the internet, ensure that the computer is set to **Obtain an IP address automatically** and **Obtain DNS server address automatically**.

4.5.3 Wireless repeating



In wireless repeating mode:

- Some functions, such as smart power saving, IPTV, WPS, and Wi-Fi schedule, are unavailable. For details, see functions displayed on the device web UI.
- When WISP mode is chosen and the LAN IP of the router is at the same network segment as that of the upstream device, the router will change the LAN IP address to a different network segment to avoid conflict.
- When Client+AP mode is chosen and the LAN IP of the router, the LAN IP address of this device may change. Visit tendawifi.com to log in to the web UI of this device.


Scenario: You have a wireless router at home and it has been successfully connected to the internet.

Goal: The signal is weak in the room far from the router. Now a new wireless router is added to extend the wireless network coverage at home.

Solution: The new router can be set to the WISP or Client+AP to reach the goal.

Assume that the wireless network information of the existing router is as follows:

- Wi-Fi name: My Wi-Fi
- Wi-Fi password: UmXmL9UK




Set the router to WISP mode


Step 1 Place the new router near the existing router and power it on.

Step 2 Set the new router to **WISP Mode**.


1. [Log in to the web UI of the router](#). Navigate to **More > Working Mode**.




2. Click **Switch Mode** after **WISP Mode**. Confirm the prompt message and click **OK**.



3. Select the Wi-Fi name of your existing router, which is **Tenda_123456** in this example. If the 2.4 GHz Wi-Fi name and 5 GHz Wi-Fi name is the same, select it as required.
4. Enter upstream Wi-Fi password, which is **UmXmL9UK** in this example, and click **Connect**. Wait until the device is restarted.



5. [Log in to the web UI of the router](#) again, and check whether the WISP mode is configured successfully as shown below.





If the connection between the upstream router and new router failed, try the following solutions:

- Ensure that the Wi-Fi password for the upstream wireless network is entered correctly, paying attention to case sensitivity, such as "Z" and "z".
- Ensure that the location of the new router is within the wireless coverage of the existing router.

Step 3 Relocate the new router by referring to the following suggestions and power it on.

- Between the existing router and the uncovered area, but within the coverage of the existing router.
- Away from microwave ovens, electromagnetic ovens, and refrigerators.
- Above the ground with few obstacles.

---End

To access the internet, connect your computer to an Ethernet port of the new router, or connect your smartphone to the Wi-Fi network of the new router.

You can find the Wi-Fi name and password on the **Wi-Fi Settings** page. If the network is not encrypted, you can also set a Wi-Fi password on this page for security.



If you cannot access the internet, try the following solutions:


- Ensure that the existing router is connected to the internet successfully.
 - Ensure that your Wi-Fi-enabled devices are connected to the Wi-Fi network of the new router.
 - If the computer connected to the router for repeating cannot access the internet, ensure that the computer is set to **Obtain an IP address automatically** and **Obtain DNS server address automatically**.
-

Set the router to Client+AP mode


Step 1 Place the new router near the existing router and power it on.

Step 2 Set the new router to **Client+AP Mode**.


1. [Log in to the web UI of the router](#). Navigate to **More > Working Mode**.




2. Tap **Switch Mode** after **Client+AP Mode**. Confirm the prompt message and tap **OK**.



3. Select the Wi-Fi name of your existing router, which is **Tenda_123456** in this example. If the 2.4 GHz and 5 GHz Wi-Fi name are the same, select it as required.
4. Enter upstream Wi-Fi password, which is **UmXmL9UK** in this example, and click **Connect**. Wait until the device is restarted.



5. [Log in to the web UI of the router](#) again, and to check whether the **Client+AP** mode is configured successfully as shown below.





If the connection between the upstream router and the new router fails, try the following solutions:

- Ensure that the Wi-Fi password for the upstream wireless network is entered correctly, paying attention to case sensitivity, such as "Z" and "z".
- Ensure that the location of the new router is within the wireless coverage of the existing router.

- Step 3** Relocate the new router by referring to the following suggestions and power it on.
- Between the existing router and the uncovered area, but within the coverage of the existing router.
 - Away from microwave ovens, electromagnetic ovens, and refrigerators.
 - Above the ground with few obstacles.

---End

To access the internet, connect your computer to an Ethernet port of the new router, or connect your smartphone to the Wi-Fi network of the new router.

You can find the Wi-Fi name and password on the **WiFi Settings** page. If the network is not encrypted, you can also set a Wi-Fi password on this page for security.



If you cannot access the internet, try the following solutions:

- Ensure that the existing router is connected to the internet successfully.
 - Ensure that your Wi-Fi-enabled devices are connected to the Wi-Fi network of the new router.
 - If the computer connected to the router cannot access the internet, ensure that the computer is set to **Obtain an IP address automatically** and **Obtain DNS server address automatically**.
-

5 Wi-Fi settings

This guide is for reference only and does not imply that the product supports all functions in the guide. The functions may differ with product models. The actual product prevails.

This chapter includes the following sections:

[Change Wi-Fi name and Wi-Fi password](#)

[Guest Wi-Fi settings](#)

[Change the Wi-Fi signal strength](#)

5.1 Change Wi-Fi name and Wi-Fi password


Step 1 [Log in to the web UI of the router.](#)

Step 2 Navigate to **WiFi Settings**.

Step 3 Enable or disable the **Unify 2.4 GHz & 5 GHz** as required. The following figure shows an example of enabling the Unify 2.4 GHz & 5 GHz.

- Enable **Unify 2.4 GHz & 5 GHz**: The Wi-Fi name and password of the 2.4 GHz and 5 GHz network on the router are the same, and only one Wi-Fi name is displayed. When you connect to your router's wireless network, you will automatically connect to the best quality Wi-Fi.
- Disable **Unify 2.4 GHz & 5 GHz**: The 2.4 GHz and 5 GHz networks on the router are displayed separately. You can access the internet through either wireless network. If you have wireless devices that only support 2.4GHz networks, you need to connect to the router's Wi-Fi network, such as security cameras, you are recommended to disable the **Unify 2.4 GHz & 5 GHz**.

Step 4 Set **WiFi Name**, **Encryption Mode**, and **WiFi Password** as required, and tap **Save** in the upper-right corner.



---End

After the settings are completed, your Wi-Fi-enabled devices (such as a smartphone) need to connect to the new wireless network to access the internet.

5.2 Guest Wi-Fi settings

The router's guest Wi-Fi is isolated from other networks. The clients connected to the guest Wi-Fi can access the internet, but cannot access the router's web UI or other networks.


When you need to open a wireless network for guests, you can enable guest Wi-Fi to meet the internet requirements of guests. It protects the security of the main network to prevent personal information disclosure.

This function is disabled by default. Assume that you want to set the Wi-Fi name of the guest network to **Tom**, and set the Wi-Fi password of the guest network to **UmXmL9UK**.

Configuration procedure:

Step 1 [Log in to the web UI of the router.](#)

Step 2 Navigate to **More > Guest WiFi**.




Step 3 Toggle on the **Guest WiFi**.

Step 4 Set **WiFi Name**, which is **Tom** in this example.

Step 5 Set **WiFi Password**, which is **Tenda+245** in this example.



Step 6 Tap **Save** in the upper-right corner.



---End

After the settings are completed, the guest's smartphone and other Wi-Fi-enabled devices can connect to the guest Wi-Fi for internet access you set, and the validity period is 8 hours.

Parameter description

Parameter	Description
Guest WiFi	Used to enable or disable the guest network function.
WiFi Name	Specify the Wi-Fi name of the router's guest network.  TIP You can change the Wi-Fi names (SSIDs) as required. To distinguish the guest network from the main network, you are recommended to set different Wi-Fi network names.
WiFi Password	Specifies the password for the router's guest network.  TIP A Wi-Fi password that contains multiple characters, such as digits, uppercase and lowercase letters, can improve Wi-Fi security.

Parameter	Description
Validity	<p>Specifies the validity period of the guest networks.</p> <p>The guest network function will be disabled automatically (The Wi-Fi enabled devices cannot scan the router's guest Wi-Fi.) out of the validity period. If the guest's visit is 8 hours, it can be set to 8 hours.</p>
Shared Bandwidth	<p>Allows you to specify the maximum upload and download speed for all clients connected to the guest networks. By default, the bandwidth is Unlimited. You can modify it as required.</p>


5.3 Change the Wi-Fi signal strength

The Wi-Fi signal strength function regulates the through-the-wall capability and coverage of the router's wireless network.


Configuration procedure:

Step 1 [Log in to the web UI of the router.](#)

Step 2 Navigate to **More > Wi-Fi Signal Strength**.



Step 3 Select the Wi-Fi signal mode as required. The following figure is for reference only.



Usually used to meet the wireless coverage requirements of small areas or obstacle-free environments.

Usually used to meet the wireless coverage requirements of medium area or few obstacles environment.

Usually used to meet the wireless coverage requirements of large areas or multi-obstacle environments.

---End

6 Network status

This guide is for reference only and does not imply that the product supports all functions in the guide. The functions may differ with product models. The actual product prevails.

This chapter includes the following sections:

[View network status](#)

[View Wi-Fi name](#)

[View the networking information](#)

[View the number of the clients](#)

[View client details](#)


[View router information](#)

6.1 View network status

[Log in to the web UI of the router](#) to view the network status.

6.1.1 Router connected to internet

When the web UI shows **Connected**, as shown in the following figure, the router is successfully connected to the internet. You can connect to the router for internet access.




6.1.2 Router disconnected from the internet

No Ethernet cable is connected to the WAN port


If “No Ethernet cable is connected to the WAN port” is displayed under the **Internet Settings**, it indicates that the Ethernet cable is improperly connected to the WAN port, as shown in the following figure.

Check whether both ends of the Ethernet cable at the WAN port are tightly connected. If the Ethernet cable is tightly connected but the problem persists, contact Tenda technical support for help.



Incorrect PPPoE username or password

If “Incorrect user name or password” is displayed under the **Internet Settings**, it indicates that the PPPoE username or password you entered is incorrect, as shown in the following figure. Tap the error message to direct to the **Internet Settings** page, re-enter the correct PPPoE username and password for internet access.




NOTE

- Note the following when entering the PPPoE username and password:
 - Case sensitive, such as "Z" and "z".
 - Distinguish between similar letters and numbers, such as the letter "l" and the number "1".
 - Enter the complete PPPoE username.
- If the PPPoE username and password are entered correctly, but the problem persists, you are recommended to tap **Advanced** to change the WAN MAC address and try again. For details, see [Modify WAN MAC Address](#). If the problem persists, contact your ISP for help.


No response from the remote server

If the “No response from the remote server” is displayed under the **Internet Settings**, as shown in the following figure. Try to solve the problem according to the on-screen prompts.



Disconnected


If the “Disconnected” is displayed under the **Internet Settings**, as shown in the following figure. Try to solve the problem according to the on-screen prompts.



6.2 View Wi-Fi name

After [logging in to the web UI of the router](#), the 2.4 GHz Wi-Fi name of the main network is displayed in the upper-left corner of the web UI.


If you want to view or set up more wireless information, refer to [Wi-Fi settings](#).




6.3 View the networking information


6.3.1 View the number of Mesh nodes

After [logging in to the web UI of the router](#), you can view the total number of Mesh nodes on the **Network Topology** page. The following figure is for reference only.







6.3.2 View network status, node and client details

After [logging in to the web UI of the router](#), navigate to the **Network Topology**, and tap any node icon  to view the networking conditions and node details, including the IP address, MAC address, and the number of clients connected to a node. The following figure is for reference only.




Parameter description

Parameter	Description
Controller	Specifies the default name of the primary node. You can customize it on the node information page.
Agent_XXXX	Specifies the default name of the secondary node. You can customize it on the node information page.
Add Node	Used to scan networking, view the methods of MESH button networking or wired networking, or view recommended solutions for networking anomalies. If you want to network, refer to the MESH networking for detailed steps.

Parameter	Description
One-Click Optimization	<p>Used to optimize wireless networks with one tap.</p> <p> TIP</p> <p>When your clients are stuck for internet access or cannot receive Wi-Fi signals, you can optimize the wireless network with one tap.</p>
One-click Reboot	<p>Used to reboot all nodes.</p> <p> TIP</p> <p>Rebooting the node will disconnect all connections. Perform this operation when the network is relatively idle.</p>
	Used to modify the node name.
IP	Specifies the IP address of the corresponding node.
MAC	Specifies the MAC address of the corresponding node.
Connection Quality	<p>Specifies the network quality of the secondary nodes.</p> <p> TIP</p> <p>If the secondary node is wired networking, the connection quality is Excellent.</p>
Online Device	Specifies the information about the client currently connected to the node, including device name and access method.
Guest Device	Specifies the information about the client currently connected to the guest network of the node, including device name and access method.
Offline Device	Specifies the offline clients.
Reboot	Used to reboot the node. Once rebooted, all connections will be disconnected. Do this when the network is relatively idle.
Delete Node	Used to remove the secondary node. Removing a node will reduce network coverage, and the node will reset to factory settings.

6.4 View the number of the clients

After [logging in to the web UI of the router](#), tap **Network Topology** to view the number of clients connected to a node.




The number at the upper-right corner of the node icon indicates the number of clients connected to the node.



6.5 View client details

6.5.1 Method 1

Step 1 After [logging in to the web UI of the router](#), tap **Network Topology**, and tap the node to which the client is connected. The following figure is for reference only.



Step 2 Tap the client to view the details according to the actual situation. The following figure is for reference only.




Tap to change the name of the clients.

IP address and MAC address of the clients.


---End

6.5.2 Method 2


After [logging in to the web UI of the router](#), tap **Device Management**. Tap the clients you want to view the details. The following figure is for reference only.



View the client details.




Parameter description

Parameter	Description
Upload	Specify the current upload or download speed of the clients.
Download	
Negotiation Speed	Specifies the maximum speed negotiated by the client with this node.
Connected Router	Specifies the node to which the clients are connected.
Smart Speed Limit	Used to limit the maximum upload or download speed of the clients.
Internet Access	<p>After this function is enabled, the clients can access the internet through this network.</p> <p>After this function is disabled, the client will be added to the blacklist. To remove it from the blacklist, refer to Remove a client from the blacklist.</p> <p> TIP</p> <p>Local Host devices do not support joining the blacklist.</p>

6.6 View router information

After [logging in to the web UI of the router](#), tap the product icon in the upper-right corner, or navigate to **More > Router Info**. You can view the system information about the router. The details are as follows:

- Basic information: Displays the system time, running time, firmware version, and hardware version of the router.
- WAN port status: Displays the IPv4 internet connection type, connection status, and IP address of the current WAN port on the router.
- LAN port status: Displays the IPv4 address, subnet mask, and MAC address of the router's LAN port.
- Wireless status: Displays basic information about the 2.4 GHz and 5 GHz wireless networks, including wireless network status, Wi-Fi name, and security.
- IPv6 status: Displays the IPv6 internet connection type, IP address, and DNS information of the current WAN port on the router.



7 Client management

This guide is for reference only and does not imply that the product supports all functions in the guide. The functions may differ with product models. The actual product prevails.

This chapter describes how to manage your clients, including:

[Add a client to the blacklist](#)

[Remove a client from the blacklist](#)

[Internet access speed control](#)

[Internet access rule control](#)


7.1 Add a client to the blacklist

The blacklisted devices cannot access the internet through the router.

To blacklist a client:

Step 1 [Log in to the web UI of the router](#), and navigate to **Client Management**.


Step 2 Locate the device that not allowed to access the internet. The following figure is for reference only.



Parameter description


Parameter	Description
All Nodes	Used to filter the clients connected to each node. When a router is networked with other routers through Mesh networking, you can tap the primary node name or other node name to display only the devices under the corresponding node.
Main Network Device	Specifies the clients connected to the main network.
Guest Device	Specifies the clients connected to guest Wi-Fi.
Offline Device	Specifies the offline clients.
Blacklist	Specifies the clients cannot access the internet through the router.

Step 3 Toggle off the **Internet Access**, confirm the prompt message, and tap **OK**.



---End


The client is removed from the device list and displayed on the blacklist now.




7.2 Remove a client from the blacklist


If the device is removed from the blacklist, it can be reconnected to the router.

Step 1 [Log in to the web UI of the router](#), navigate to **Client Management**, and tap **Blacklist**.

Step 2 Locate the client you want to remove from the blacklist, and tap . The following figure is for reference only.



Step 3 Confirm the prompt message, and tap **OK**.



---End

7.3 Internet access speed control


You can control the bandwidth of the devices connected to the router, so that the limited bandwidth is properly allocated.

Scenario: You want all the devices connected to the router to watch 1080P HD video and enjoy a good internet experience.

Solution: You can configure the Smart Speed Limit function to reach the goal.

Step 1 [Log in to the web UI of the router](#), and navigate to **Client Management**.



Step 2 Locate and tap the device according to the device name. The following figure is for reference only.



Step 3 Tap **Smart Speed Limit**, toggle on the **Smart Speed Limit**, set **Download** to **1000 KB/s** in this example, and tap **Save** in the upper-right corner.



To ensure that the video definition of the client is 1080P, it is recommended that the internet speed limit of the mobile client is 512KB/s, and the internet speed limit of the computer client is 1000KB/s.



---End

7.4 Internet access rule control

With parental control function, you can configure various parental control rules to control access to certain websites or block certain clients from accessing the internet.

Scenario: You want to configure your kid's internet access through the router. Your kid cannot access such websites as Facebook, Twitter and Instagram from 8:00 to 22:00 on Sunday.


Goal: Devices cannot access to websites include kid's phones and computers.

Solution: You can configure a parental control rule to reach the goal.


To add such a rule:

Step 1 [Log in to the web UI of the router](#), and navigate to **Parental Control**.


Step 2 Tap **Enable Parental Control** or  in the upper-right corner.



Step 3 Set **Group Name**, which is **Kid's phone and computer** in this example.



Step 4 Tap **Add Device**, select the client to be added to the group, which is **kid's phone and computer** in this example, and tap **Save** in the upper-right corner.




Step 5 Set the time when the client can access the internet.

1. Tap **Internet Time**, and set control period of the client.




TIP

The system creates a time rule by default. If the requirements are different, manually change it. You can tap + in the upper-right corner to add multiple online periods as required.




2. Set the **Start Time**, **End Time** and the date to access the internet, which are **00:00-23:59** and **Sunday** in this example, and tap **Save** in the upper-right corner.




Step 6 Set the URL that the client is forbidden to access.


1. Back to **Parental Control** page, and tap **URL Filter**.
2. Toggle on the **URL Filter**, and select **Filter mode** to **Block access to URLs**.
3. Tap **+** to add URLs.



4. Enter **Facebook** for URL.
5. Repeat substeps 3 to 4 to add **Twitter** and **Instagram**, and tap **Save** in the upper-right corner.



Step 7 Back to **Parental Control** page, and tap **Save** in the upper-right corner.



The URL filter supports keywords, does not support Chinese characters. If you want to be precise blocked the URL, enter the full URL, such as www.google.com.

---End

After the settings are completed, your kid's phone and computer can access any websites except for Facebook, Twitter and Instagram from 00:00 to 23:59 on Sunday.

8 Optimize network performance


This guide is for reference only and does not imply that the product supports all functions in the guide. The functions may differ with product models. The actual product prevails.

If you get stuck when you access the internet, you can try to optimize the wireless network with one tap to solve the problem.


Configuration procedure:

Step 1 [Log in to the web UI of the router](#), and navigate to **Network Topology**.

Step 2 Tap  (**One-Click Optimization**).



Step 3 Confirm the prompt message, and tap **Optimization**.



---End

9 Turn on or turn off the indicator of router

This guide is for reference only and does not imply that the product supports all functions in the guide. The functions may differ with product models. The actual product prevails.

This chapter describes how to manage your clients, including:

[Turn on or turn off the indicators of all nodes](#)


[Schedule turn off the indicators of all nodes](#)

[Turn on or turn off the indicators of single node](#)

9.1 Turn on or turn off the indicators of all nodes

9.1.1 Method 1


After [logging in to the web UI of the router](#), tap **Network Topology**, and tap  (LED Indicator). The following figure is for reference only.




9.1.2 Method 2

Step 1 [Log in to the web UI of the router.](#)

Step 2 Navigate to **More > LED Indicator**.



Step 3 Turn on or turn off the **LED Indicator Management** as required. The following figure is for reference only.



---End

9.2 Schedule turn off the indicators of all nodes


You can turn off the indicators of all nodes as required to save power.

Assume that you want to turn off the router's indicator from 22:00 to 7:00, and other periods are normal. For details, see the following steps.

Configuration procedure:


Step 1 [Log in to the web UI of the router.](#)

Step 2 Navigate to **More > LED Indicator**.



Step 3 Toggle on the **LED Indicator Management** and **Disable Period**.

Step 4 Set the period for the router's indicator to be off, and tap **Save** in the upper-right corner. The following figure is for reference only.




---End

After the settings are completed, the indicator of all nodes goes off during the **Disable Period**. Outside this period, each indicator works normally.


9.3 Turn on or turn off the indicators of single node

Step 1 [Log in to the web UI of the router.](#)

Step 2 Tap **Network Topology**, and tap the node whose indicator you want to turn on or turn off. The following figure is for reference only.



Step 3 Turn on or turn off the indicator of the node as required.




---End

10 Change the router's login password

This guide is for reference only and does not imply that the product supports all functions in the guide. The functions may differ with product models. The actual product prevails.

For the network security, it is recommended that you change the login password of the router's management page regularly.


Step 1 [Log in to the web UI of the router](#), and navigate to **More > Login Password**.



Step 2 Enter the current login password in **Old Password** box.

Step 3 Set login password in **New Password** box.

Step 4 Tap **Save** in the upper-right corner.



---End

The browser will direct to the login page, enter the password you set, and then tap **Login** to log in to the web UI of the router again.

11

System maintenance

This guide is for reference only and does not imply that the product supports all functions in the guide. The functions may differ with product models. The actual product prevails.

This chapter describes how to manage your clients, including:

[Reboot device](#)

[Firmware upgrade](#)

[Reset](#)

11.1 Reboot device


If a parameter you set does not take effect or a node cannot be used, you can manually reboot the node to resolve the problem. The reboot will disconnect all connections. Perform this operation when the network is relatively idle.

11.1.1 Reboot all nodes


Method 1

Step 1 [Log in to the web UI of the router.](#)

Step 2 Tap **Network Topology**, and tap **One-click Reboot**. The following figure is for reference only.



Step 3 Confirm the prompt message, and tap **Reboot**. The following figure is for reference only.




---End



Wait until the ongoing process finishes.

Method 2

Step 1 [Log in to the web UI of the router](#), and navigate to **More > Reboot**.



Step 2 Tap **One-click Reboot**. Confirm the prompt message, and tap **Reboot**. The following figure is for reference only.



---End


Wait until the ongoing process finishes.


11.1.2 Reboot single node



Method 1

Step 1 [Log in to the web UI of the router.](#)

Step 2 Tap **Network Topology**, locate and tap the node you want to reboot. The following figure is for reference only.



Step 3 Tap  (**Reboot**). Confirm the prompt message, and tap **Reboot**.




---End



Wait until the ongoing process finishes.

Method 2

Step 1 [Log in to the web UI of the router](#), and navigate to **More > Reboot**.



Step 2 Locate a node that you want to reboot and tap **Reboot**. Confirm the prompt message, and tap **Reboot**. The page will be prompted to reboot, please wait with the patient. The following figure is for reference only.



---End


11.2 Firmware upgrade

With this function, you can upgrade the firmware of the router to obtain the latest functions and more stable performance. The router supports online upgrade and local upgrade.

NOTE

- Do not disconnect the device from power or internet during this process. Otherwise, the upgrade may fail or the router may be damaged.
- After completing the upgrade for better stability and added features of the higher version firmware, please restore the router to its factory settings and reconfigure all internet parameters.

[Log in to the web UI of the router](#), and navigate to **More > Firmware Upgrade**. If a new version is found, follow the on-screen instructions to upgrade the router's firmware. The following figure is for reference only.



The system will download the upgrade firmware from the cloud and upgrade automatically. Please wait with patience.

After the upgrade is completed, access the [Router Info](#) page again and check whether the upgrade is successful.

11.3 Reset

When the network cannot locate the problem or you want to log in to the web UI of the router but forgot the login password, you can restore the router to factory settings and reconfigure.

NOTE


- Resetting clears all configurations and restores the router to factory settings. You need to reconfigure the router. You are recommended to back up the configuration before restoring the factory settings.
- During the process of restoring factory settings, ensure that the router is powered properly to avoid damage to the router.
- After the router is restored to factory settings, the default login IP address of the router is **192.168.0.1**.

11.3.1 Reset all modes

You can restore the entire network to factory settings by restoring all nodes to factory settings.



Step 1 [Log in to the web UI of the router.](#)

Step 2 Navigate to **More > Reset**.



Step 3 Tap **Restore to Factory Settings** on the bottom page.

Step 4 Confirm the prompt message, and tap **OK**.



---End

Wait until the ongoing process finishes.

11.3.2 Reset a node



Resetting clears all configurations and restores the router to factory settings. Please operate with caution. You are recommended to back up the configurations first.


Method 1 (Only for secondary node)

By removing the secondary node, the node can be restored to the factory settings and will no longer automatically join the network. For details, see [Remove the secondary node from the network](#).

Method 2


Step 1 [Log in to the web UI of the router.](#)

Step 2 Navigate to **More > Reset**.



Step 3 Locate the node that you want to restore to factory settings and tap the corresponding **Reset**. The following figure is for reference only.

Step 4 Confirm the prompt message, and tap **OK**.



---End

Wait until the ongoing process finishes.

12



More functions

This guide is for reference only and does not imply that the product supports all functions in the guide. The functions may differ with product models. The actual product prevails.

[Log in to the web UI of the router](#), navigate to **More**, and tap **Click to visit the webpage version** to configure more functions.



For detailed configuration of more functions, refer to the router's **Desktop Website User Guide** you purchased.



Appendixes

A.1 FAQ

Q1: I cannot log in to the web UI by visiting tendawifi.com. What should I do?

A1: First, try to visit <http://tendawifi.com> or <http://192.168.0.1> in the address bar (not the search bar).

If you are using a Wi-Fi-enabled device, such as a smartphone:

- Ensure that your smartphone is connected to the Wi-Fi network of the router.
 - For the first login, connect the Wi-Fi name (@Tenda_XXXXXX) on the label of the device's body. XXXXXX is the last six digits of the MAC address on the label.
 - When logging in again after settings, use the changed Wi-Fi name and password to connect to the Wi-Fi network.
- Ensure that the cellular network (mobile data) of the smartphone is disabled.

If you are using a wired device, such as a computer:

- Ensure that the computer is connected to an Ethernet port (If the WAN/LAN auto-negotiation function is disabled, connect the computer to any Ethernet port 2/3/4 of the router.) properly.
- Ensure that the computer is set to **Obtain an IP address automatically** and **Obtain DNS server address automatically**.

If the problem persists, reset the router by referring to [Q3](#) and try again.

Q2: I cannot access the internet after the configuration. What should I do?

A2: Try the following solutions:

- Ensure that the WAN port of the router is connected to a modem or Ethernet jack properly.
- Log in to the web UI of the router and navigate to the [Internet settings](#) page. Follow the instructions on the page to solve the problem.

If the problem persists, try the following solutions:

- For Wi-Fi-enabled devices:
 - Ensure that your devices are connected to the Wi-Fi network of the router.
 - Visit tendawifi.com to log in to the web UI and change your Wi-Fi name and Wi-Fi password on the **WiFi Settings** page. Then try again.
- For wired devices:
 - Ensure that your wired devices are connected to an Ethernet port (If the WAN/LAN auto-negotiation function is disabled, connect the computer to any Ethernet port 2/3/4 of the router.) properly.
 - Ensure that wired devices are set to **Obtain an IP address automatically** and **Obtain DNS server address automatically**.

Q3: How to restore my device to factory settings?

A3: Hold down the reset button (Marked as **RST** or **RESET**) of your device for about 8 seconds, and the router is reset successfully. For more methods, see [Reset](#).

Q4: Why cannot I find the Wi-Fi signal of the router?

A4: Connect your computer to Ethernet port (If the WAN/LAN auto-negotiation function is disabled, connect the computer to any Ethernet port 2/3/4 of the router.) of the router, and log in to the web UI. Navigate to **WiFi Settings** and ensure that the Wi-Fi name does not contains any Chinese characters.

Q5: I cannot find the 5 GHz Wi-Fi network of the router on my Wi-Fi-enabled device. What should I do?

A5: Try the following solutions:

- Only devices supporting 5 GHz network can find and connect to the 5 GHz Wi-Fi network.
- Log in to the web UI of the router, and check whether you have enabled **Unify 2.4 GHz & 5 GHz**. After it is enabled, the 5 GHz Wi-Fi name is the same as the 2.4 GHz Wi-Fi name.
- If the **Unify 2.4 GHz & 5 GHz** function is disabled on the router but the smartphone can search for another 5 GHz Wi-Fi network, reset the router by referring to [Q3](#) and try again.

Q6: The router's Wi-Fi signal is poor. What should I do?

A6: Try the following solutions:

- Place the router in a high position with few obstacles.
- Keep your router away from electronics with strong interference, such as microwave ovens, induction cookers, and refrigerators.
- Keep your router away from metal barriers, such as weak current boxes, and metal frames.

Q7: If the network speed is slow after I connect my device to the router. What should I do?

A7: Try the following solutions:

- For Wi-Fi-enabled devices, such as a smartphone:
 - Try to get close to your router to test the network speed when the wireless signal strength is full. If the network speed is fast when the signal is strong, it indicates that the signal coverage is weak, resulting in a slow network speed, and the wireless network can be extended by adding new secondary nodes or wireless adapters.
- For wired devices, such as a computer:
 - Ensure that the Ethernet cable is connected properly.
 - Ensure that the [Bandwidth control](#) are not configured on the router. If yes, delete related configurations and check whether the network speed is restored.

- Loading too many applications in the background will lead to insufficient computer system resources. Please load software properly or delete unnecessary programs and files to free up resources to improve network speed.

Q8: If the device is disconnected from the router. What should I do?

A8: Try the following solutions:

- If the Wi-Fi-enabled device goes offline, the wired device can access the internet normally:
 - Refer to [Q6](#) to place the router in an appropriate position.
 - Check whether the wireless adapter driver of the Wi-Fi-enabled device is faulty. Replace the wireless adapter driver with another device or update the wireless adapter driver.
 - If the problem persists, reset the router by referring to [Q3](#) and try again.
- If the wired device goes offline, the Wi-Fi-enabled device can access the internet normally:
 - If the Ethernet cable between the computer and the router is too long or poor quality, it will cause the cable drop. Please replace the short Ethernet cable.
 - Try to replace the Ethernet port (If the WAN/LAN auto-negotiation function is disabled, connect the computer to any Ethernet port 2/3/4 of the router.) connection or use another computer connection.
- If both wired and Wi-Fi-enabled devices go offline:
 - Log in to the web UI of the router and ensure that the router is properly connected to the internet. If not, refer to [Router disconnected from the internet](#) to solve.
 - Refer to [Q6](#) to place the router in an appropriate position.
 - Ensure that the Ethernet port is connected properly, and replace a short Ethernet cable to connect to the Ethernet port. If the WAN/LAN auto-negotiation function is disabled, connect the modem or Ethernet jack to the Ethernet port 1 (WAN port).
 - When not connected to the router, directly connect the Ethernet cable to the computer to check whether the internet is disconnected. If the internet is disconnected from the internet, contact your ISP for help.
 - If the problem persists, reset the router by referring to [Q3](#) and try again.

Q9: The networking fails. What should I do?

A9: Try the following solutions:

- Ensure that the new router is reset. If not, restore the router to factory settings first.
- Ensure that the existing router (primary node) is connected to the internet, and then refer to [MESH networking](#) and try again.

Q10: Some computers cannot search router's Wi-Fi. What should I do?

A10: Try the following solutions:

- Change the network mode of the router's 2.4G Wi-Fi and 5G Wi-Fi to not include 802.11ax and 802.11be, and search again.
- If the router's Wi-Fi can be searched after changing the network mode, the wireless network adapter version is older and needs to be updated. You can go to the corresponding official website of the wireless network adapter to download and install, or you can use software such as driver wizard to detect and update online.
- If only 2.4G Wi-Fi is searched, first check whether the computer supports 5G band. If other 5G Wi-Fi can be searched, change the 5G Wi-Fi channel of the router to channel 36 or channel 149 in turn, and then search. If it can be searched after changing the channel, it means that the 5G wireless network adapter only supports high-channel or low-channel Wi-Fi.

A.2 Acronyms and Abbreviations

Acronym or Abbreviation	Full Spelling
AES	Advanced Encryption Standard
AP	Access point
DDNS	Dynamic Domain Name System
DHCP	Dynamic Host Configuration Protocol
DHCPv6	Dynamic Host Configuration Protocol for IPv6
DMZ	Demilitarized zone
DNS	Domain Name System
DSL	Digital subscriber line
DST	Daylight Saving Time
FTP	File Transfer Protocol
ICMP	Internet Control Message Protocol
IP	Internet Protocol
IPTV	Internet Protocol television
IPv4	Internet Protocol version 4
IPv6	Internet Protocol version 6
ISP	Internet service provider
L2TP	Layer 2 Tunneling Protocol
LAN	Local area network
LED	Light-emitting diode
MAC	Medium access control
MPPE	Microsoft Point-to-Point Encryption
MTU	Maximum Transmission Unit
PD	Prefix Delegation

Acronym or Abbreviation	Full Spelling
PoP	Post Office Protocol
PPPoE	Point-to-Point Protocol over Ethernet
PPTP	Point to Point Tunneling Protocol
RA	Router Advertisement
SN	Serial Number
SSID	Service Set Identifier
STB	Set-top box
TCP	Transmission Control Protocol
UDP	User Datagram Protocol
UI	User interface
UPnP	Universal Plug and Play
URL	Uniform Resource Locator
USB	Universal Serial Bus
VLAN	Virtual local area network
VPN	Virtual private network
WAN	Wide area network
WISP	Wireless Internet Service Provider
WLAN	Wireless local area network
WPA	Wi-Fi Protected Access
WPA-PSK	WPA Pre-shared Key
WPA3-SAE	WPA3-Simultaneous Authentication of Equals
WPS	Wi-Fi Protected Setup